




# WALL TERMINATION WITHOUT COVE

Installed at floor/wall where no cove is specified and where movement is anticipated. If floor/wall joint movement is not anticipated, the flooring system may terminate wall without expansion joint material.

Numbering shows order of installation.



WALL TERMINATION WITHOUT COVE